



COMPONENTS:

- 1 Tether
- 1 Screw
- 1 Small Washer
- 1 Locking Nut
- 1 Large Washer



- 1 Put the tether through the eyelet on the bin.



- 2 Loop one end of the tether through its other end.



- 3 Place the screw through the large washer and then the loose end of the tether.



- 4 Put the screw through the hole on the lid.



- 5 Place the small washer on the end of the screw and thread the locking nut onto screw.



- 6 Tighten using a 3/8" (or 10mm) Nut Driver and a size 2 Phillips screwdriver.