

## INSTALL INSTRUCTIONS

## GO / CLEANLI™ GO - LID GROMMETS

We understand that wipes are not always available due to the high demand. To accommodate the needs of our customers, this grommet can be swapped with the one on your unit to provide a higher resistance to wipes being pulled through. Some thicker wipes may pull through the softer grommet already installed in your unit better, while some thinner wipes may pull through the harder grommet provided as an alternative. With both, you can ensure your unit is performing the best for your needs regardless of the supply of wipes you have at the time.

## STEP-BY-STEP INSTRUCTIONS





To remove existing soft rubber grommet from lid, follow steps below.

- Remove the lid from the body of your container and place on a flat surface, (Fig. 1)
- From the top of the lid, using your thumb, push edge of the rubber grommet towards center of hole and push down. Grommet will squeeze off rim and you can remove completely. (Fig. 2)







To install new teal rubber grommet in lid, follow steps below.

- Holding outer edges of new teal grommet between index finger and thumb, gently squeeze to slightly bend grommet edges downward. (Fig. 3)
- Holding grommet in curved position parallel to lid, push front edge of grommet slotting against rim of hole. (Fig. 4)
- Continue slotting around rim until grommet is fully installed. (Fig. 5)
- 1-800-565-9931

