



1. Align the flat side of the magnets to the middle holes on the back of the unit. (FIG 1)
2. Insert the screws through the magnet holes at the back (FIG 1)
(the screw head should be within the inset area of the magnet)
3. Fasten the bolts to the screws from the other side. (FIG 2)