

### TOOLS REQUIRED:



Ratchet with 9/16" socket




1/2" Masonry Drill Bit



Drill

### HARDWARE PROVIDED FOR ASSEMBLY:



3" Lag Bolts



FIG. 1



FIG. 2



FIG. 3

### STEP-BY-STEP INSTRUCTIONS

- 1 Place unit in its location.
- 2 Drill through guide holes in the bottom of the container with 1/2" masonry drill bit. (FIG. 1)
- 3 Place large bolt in hole and hammer until flush with base. (FIG. 2)
- 4 Tighten with a 9/16" socket and repeat step 2 for the rest of the holes. (FIG. 2 & 3)