





TOOLS REQUIRED:



5/32" (4mm)

Hex Key / Allen Wrench (not included)

INCLUDED HARDWARE:



(4) Chicago Bolts



(4) 5/16" Washers

PLEASE NOTE: Hardware listed reflects what is required for 1 body sign.



FIG. 1



FIG. 2



FIG. 3

STEP-BY-STEP INSTALLATION INSTRUCTIONS

- 1 Choose the side you want to install your body sign on and remove the 4 hole plugs to expose the threaded bolt inserts. **(FIG. 1)**
- 2 Align the holes in the body sign directly over threaded bolt inserts so that all 4 holes align. **(FIG. 2)**
- 3 Insert a Chicago bolt with a washer through signage and hand thread into each threaded insert. Once you have all 4 Chicago bolts and washers hand tightened, align sign on body and tighten each bolt using a 5/32" (4mm) hex key/Allen wrench until snug. **(FIG. 3)**
- 4 Repeat steps 1 - 3 until desired amount of signage is installed.

