


TOOLS REQUIRED:



- . 3/8" (or 10mm) Nut Driver
- . Size #2 Robertson Screwdriver



INCLUDED HARDWARE:



x2) Screws



x2) Washers



x2) Locking Nuts
3/8" or 10mm



STEP-BY-STEP INSTRUCTIONS

- 1 Locate the slit along the top rim of the body
- 2 Feed 1 eyelet* of tether internally through the body (FIG. 1)
**Note: Eyelet should sit flush to the internal side of the body resting above the hole in body. The opposite end eyelet of tether should be resting outside of the body.*
- 3 Thread in 1 screw from outside the body into predrilled hole and through the tether eyelet then place washer on screw and thread on 1 locking nut until resistance is felt (FIG. 2)
- 4 Locate lid that is to be attached and find side of lid that contains 1 predrilled hole within the label area (FIG. 3)

Continued on Page 2



STEP-BY-STEP INSTRUCTIONS CONTINUED

- 5 Place lid on body as shown in **(FIG. 4)** and thread 1 screw from outside of lid into hole in lid, slip tether eyelet over screw on inside of lid, then place on washer and thread on locking nut until resistance is felt
- 6 Lid tether is now fully installed and lid can be properly placed onto body, then lid labels can be applied **(FIG. 5)**
- 7 Place Renegade in desired location