



YOU HAVE:



Single Dolly

OR



Dolly Set

INCLUDED IN YOUR EXPANSION PACK:



1x Expansion Dolly



2x Bolts



2x Locking Nuts

PLEASE NOTE:

You are able to combine XL Expansion Dollies with Standard Waste Watcher Dollies.



- 1 Line up the square hole on your Expansion Dolly with the round hole on the Single Dolly, by lifting the Expansion Dolly over the wheel axle on the Single Dolly.



- 2 Insert one of the bolts through the front hole into the Single Dolly. The bolt will rest flush against the Expansion Dolly, fitting snugly into the square hole. Thread the nut onto the bolt.



- 3 Hold the bolt against the Expansion Dolly, making sure it is properly situated in the square hole and use an 7/16" (or 11mm) Nut Driver to tighten the nut.



- 4 Repeat Steps 2 and 3 on the back, and continue to add Expansion Dollies to either side of your Dolly Set until you have reached the number of streams you require for your program.