



SIGN FRAME KIT CONTAINS:

- 1 x WW Sign Frame Support Block
- 1 x WW Sign Frame with Plexi Sheet installed
- 1 x Signage as purchased



STEP-BY-STEP INSTRUCTIONS

- 1 Locate the WW Sign Frame Support Block
- 2 Take the WW Sign Frame Support Block (tabs facing to the back) and feed into the rim holes located at the back of the Waste Watcher body. *Note - A snap will be heard once Support Block is engaged into body. Support block has now been installed into the Waste Watcher body. **(FIG. 1)**
- 3 From the top of the sign frame, slowly feed your signage into the WW Sign Frame until fully inserted. **(FIG. 2)**
- 4 Snap bottom of Waste Watcher Sign Frame into exposed holes in the WW Support Block. *Note - A snap will be heard once Sign Frame has been successfully installed. **(FIG. 3)**

To Remove WW Sign Frame & Change Out Signage:

Locate the Sign Frame tabs at the back of the Support Block, with gently force flex tab away from the bin. Do this step until each of the 2 tabs have disconnected from the Support Block. Support block should still remain engaged to the body. **(FIG. 4)**

Slide signage upwards until signage is exposed at the top of the frame, remove and insert new signage. Return Sign Frame to Waste Watcher body and snap into installed Support Block. Waste Watcher Sign Frame has been reinstalled.

