



TOOLS REQUIRED:



Ratchet with 9/16" socket



1/2" Masonry Drill Bit




#2 Robertson Screwdriver



Hammer Drill


HARDWARE PROVIDED FOR ASSEMBLY:



(4) Steel Bracket



(4) Lag Bolt



(24) Screws



FIG. 1



FIG. 2



FIG. 3

STEP-BY-STEP INSTRUCTIONS

- 1 Place unit in its location.
- 2 Place steel bracket against the post centered on the outside edge flush with ground. Drill through hole in the bottom of bracket with 1/2" masonry drill bit. (FIG. 1)
- 3 Using holes on vertical side of bracket, use supplied screws to fasten bracket to post. (FIG. 2)
- 4 Place lag bolt in hole, then tighten with a 9/16" socket. (FIG. 3)
- 5 Repeat steps 2 to 4 for the remaining brackets (FIG. 1, 2, 3)